




LG SmartTV Configuration

1. hold "Settings" on IR remote for 5 sec till you see the settings menu, still hold "Settings" until the menu disappears, now quickly press on IR remote "1" "1" "0" "5" "ok"
2. LG Hotel Mode Settings look screenshot:







###CAUTION! "Menu Display" should be ON, if you want to use Screen Sharing and Smart Share!



3. Network Settings look screenshot:

Select fix or DHCP, wired or wireless






4. Pro Centric settings look screenshot:

Domain Name: setup.triax.biz:9090

Please Enter it like this...


...via Wizard




...via Options



5. General => Configuration Setup





The image shows the 'CONFIGURATION SETUP' menu on an LG SmartTV. On the left is a vertical sidebar with icons and labels for different settings categories: 'LG Hotel Mode' (building icon), 'Network' (globe icon), 'Pro:Centric' (circular arrow icon), 'General' (wrench and screwdriver icon), 'Media Share' (music note icon), and 'TV Manager' (TV icon). The main area displays a list of settings: 'DTV Programme Update' (Manual), 'On Timer Operation' (Once), 'Scart Out' (Enable), 'Radio Name Display' (Off), '15Min Auto Off' (Off), 'Auto Sensing', 'Instant On' (Off), and 'Instant On Mute'. The 'Instant On Reboot' option is highlighted in a red bar at the bottom of the list. In the bottom left corner, the software version 'S/W: 0311.60' and 'Micom: 03.16' are displayed.

CONFIGURATION SETUP

LG Hotel Mode

Network

Pro:Centric

General

Media Share

TV Manager

S/W: 0311.60
Micom: 03.16

DTV Programme Update ▾
Manual ^

On Timer Operation ▾
Once

Scart Out ▾
Enable

Radio Name Display ▾
Off

15Min Auto Off ▾
Off

Auto Sensing

Instant On ^
Off

Instant On Mute

✓ Instant On Reboot ▾